

SILICON LIGHTWORKS


CL-700 / SL-700 Exhibit Lights User Instructions

TRADITIONAL "PLUG-IN" OPERATION: To operate your lights from a traditional wall outlet or power strip please refer to Diagram 1 below:

Diagram 1

(your model & color may vary)

Step 2: Plug the included AC Adapter into any wall outlet or power strip



* You may link/power up to 4 lights at once using our Standard AC Adapter and up to 8 lights at once using our High-Power AC Adapter.

To Turn Off: Simply unplug the Power Cable from the AC Adapter. Or, if using our optional Inline Power Switch (sold separately), toggle the "on/off" button to the off position.

User Instructions Cont'd

BATTERY OPERATION: To operate your lights using our optional Li-ion Mobile Power Center Battery (sold separately) please refer to Diagram 2 below:

Diagram 2

(your model & color may vary)



- * You may link/power up to 4 lights at once using our Battery. Please refer to the Quick Start Guide included with each Battery for additional important information (charging, storage, capacity check, etc).

User Instructions Cont'd



LIGHT ATTACHMENT: On every bracket or clamp you will find an 18mm wide track that pairs with the 2 opposable guide rails found at the base of every light. To attach a light to a bracket or clamp, simply slide the opposable guide rails onto the 18mm track, which will secure the light in place.

ARM ANGLE ADJUSTMENT: To adjust the arm angle of your light, simply loosen the Phillips-head set screw located at the light's base and adjust the arm to a desired angle. Once adjusted, tighten the set screw to lock the new angle into place.

