


SILICON LIGHTWORKS


Mobile Power Center ("MPC") User Instructions

* **CHARGING**: We have shipped your Mobile Power Center ("MPC") charged at roughly 30%. As a result, you will need to fully charge the MPC to utilize its full capacity. To do so:

Step 1: Plug the included Charge Connector into the AC Adapter to create a "male" connector tip.




Step 2: Plug the newly created male connector tip of the AC Adapter into the red Input port on the top of the MPC.



Step 3: Plug the AC Adapter into any standard outlet. The MPC capacity indicator lights will blink while charging and remain fully illuminated when fully charged. Fully charges in approximately 5 hours.

* Charge only with the included Silicon Lightwork's AC Adapter and always disconnect the AC Adapter when fully charged.


POWERING ON: Quickly press & release (“quick press”) the Power Button to turn on the MPC (see picture below). If a device (i.e. light, cell phone, tablet, etc.) is connected to the green Output port or USB port, power will begin to flow. If no device is connected, the MPC will automatically power-off after roughly 25 seconds.



POWERING OFF: Gently press & hold (“long press”) the Power Button for roughly 3 seconds to turn off the MPC. The MPC will also automatically shut off if you unplug an illuminated fixture (or chain of fixtures).

CAPACITY CHECK: To check capacity, quick press the Power Button and view the 4 indicator lights on the front of the MPC. The capacity remaining corresponds to the number of lights that illuminate:

- ● ● ● 4 Illuminated = 75 - 100%
- ● ● 3 Illuminated = 50 - 75%
- ● 2 Illuminated = 25 - 50%
- 1 Illuminated = 5 - 25%
- ● 1 Blinking = 0 - 5%



PRO TIP: When storing your MPC for extended periods (10+ days), always maintain a state of charge between 30-70% (2 or 3 lit indicator lights). This will maximize battery life & performance.

For more information please visit our website at:

siliconlightworks.com